
C150-E100-01EN

# M3097DE/DG Image Scanner


Operator's Guide





# M3097DE/DG Image Scanner

Operator's Guide



Edition	Date published	Revised contents
01	December, 1997	First edition
	Specification	on No. C150-E101-01EN

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This digital apparatus does not exceed the Class A limit for radio noise emissions from digital apparatus set out in the Radio interference Regulations of the Canadian Department of Communications.

Le pésent appareil numérique n'ément pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la classe A prescridtes dans le Réglesment sur le brouillage radioélectrique dicté par le ministere des Communications du Canada.

MaschinenlärmInformationsverordnung 3. GSGV, 18.01.1991:Der arbeisplatzbezogene Schalldruckpegel beträgt 70dB(A)oder weniger gemäß ISO 7779.

The contents of this manual may be revised without prior notice.

All Rights Reserved, Copyright © 1997 FUJITSU LIMITED. Printed in Japan.

No part of this manual may be reproduced in any form without permission.

# Please send your comments on this manual or on Fujitsu products to the following addresses:

FUJITSU COMPUTER PRODUCTS OF AMERICA,INC. 2904 Orchard Parkway,San Jose. California 95134-2022,U.S.A. TEL:1-408-432-6333 FAX:1-408-432-3908 Home page:http://www.fcpa.com/

FUJITSU AUSTRALIA LIMITED 475 Victoria Avenue Chatswood. N.S.W2067,AUSTRALIA TEL:61-2-410-4555 FAX:61-2-411-8603

FUJITSU CANADA,INC. 2800 Matheson Blvd.East,Mississauga. Ontario 4X5,CANADA TEL:1-905-602-5454 FAX:1-905-602-5457

FUJITSU DEUTSCHLAND GmbH. Frankfurter Ring 211, 8000 München 40,F.R,GERMANY TEL:49-89-32378-0 FAX:49-89-32378-100

FUJITSU ESPAÑA,S.A Edificio torre Europa 5ª Paseo de la Castellana 95 Madrid 28046,SPAIN TEL:34-1-581-8400 FAX:34-1-581-8125

FUJITSU EUROPE LTD.
2,Longwalk Road,Stockey Park,Uxbridge
Middlesex,UB11 1AB,U.K
TEL:44-81-573-4444
FAX:44-81-573-2643
Home page:http://www.fujitsu-europe.com/

FUJITSU FRANCE S.A.
Bâtiment Aristote,17 rue Olof palme
94006 Créteil cedex,FRANCE
TEL:33-14-513-1616
FAX:33-14-399-0700

FUJITSU HONG KONG Limited Room 2521,Sum Hung Kai Centre 30 Harbour Road Wanchal,Hong Kong TEL:852-827-5780 FAX:852-827-4724 TLX:62667

FUJITSU ITALIA S.p.A. Via Melchiorre Gioia,No.8-20124 Milano,ITALY TEL:39-2-6351 FAX:39-2-6572257

FUJITSU NORDIC AB Kung Hans vag,S-19176 Sollentuna,SWEDEN TEL:46-8-626-6000 FAX:46-8-626-6711

FUJITSU LIMITED
International Operations
Marunouchi 1-6-1, Chiyoda-ku,Tokyo 100
JAPAN
TEL:(81-3)3216-3211
FAX:(81-3)3213-7174
TLX:J2283
Cable:"FUJITSU LIMITED TOKYO"
Home page:http://www.fujitsu.co.jp/

### IMPORTANT NOTE TO USERS

READ CAREFULLY ALL OF THIS MANUAL BEFORE USING THIS PRODUCT. IF NOT USED CORRECTLY, UNEXPECTED DAMAGES MAY BE CAUSED TO THE USERS OR THE BYSTANDERS.

While all efforts have been made to ensure the accuracy of all information in this manual, FUJITSU assumes no liability to any party for any damage caused by errors or omissions or by statements of any kind in this manual, its updates or supplements, whether such errors are omissions or statements resulting from negligence, accidents, or any other cause. FUJITSU further assumes no liability arising from the application or use of any product or system described herein; nor any liability for incidental or consequential damages arising from the use of this manual. FUJITSU disclaims all warranties regarding the information contained herein, whether expressed, implied, or statutory.

FUJITSU reserves the right to make changes to any products herein, to improve reliability, function, or design, without further notice and without obligation.

### **Preface**

This manual explains how to use the M3097DE/DG image scanner.

This manual contains COMPONENTS, INSTALLATION AND CONNECTION, OPERATING INSTRUCTION, DOCUMENT SPECIFICATION, SPECFICATIONS and SETUP MODE.

Refer to "Cleaning and Maintenance" for the information about the routine operation of the M3097DE/DG.

Reference Guide contains OPERATING INSTRUCTION, CLEANING, REPLACEMENT OF PARTS, ADJUSTMENT and TROUBLESHOOTING.

The M3097DE/DG is very fast and highly functional image scanner developed for volume filing, using charge-coupled device (CCD) image sensors. This scanner features duplex scanning and high quality image, processing with an automatic document feeder (ADF).

### Conventions

Special information, such as warnings, cautions are indicated as follows:

#### **WARNING**

WARNING indicates that personal injury may result if you do not follow a procedure correctly.

#### **CAUTION**

CAUTION indicates that damage to the scanner may result if you do not follow a procedure correctly.

The following symbols are used in this manual.



Used for general WARNING and CAUTION.



Be careful not to pinch your fingers or hands.

# **CONTENTS**

□ CHAPTER 1	COMPONENTS Checking the Components Units and Assemblies Operator Panel	.1-2
□ CHAPTER 2	INSTALLATION AND CONNECTIONS Precautions Inspection Removing the Carrier Fixing Bracket Cable Connection Mounting the Stacker SCSI-ID setting (M3097DG)	.2-2 .2-4 .2-5 .2-7
□ CHAPTER 3	OPERATING INSTRUCTION Turning the Power On	. 3-2
□ CHAPTER 4	ADF DOCUMENT SPECIFICATION  Document Size  Document Quality	
□ CHAPTER 5	SPECIFICATIONS Installation Specifications Dimensions Consumables Option	.5-2 .5-3
□ CHAPTER 6	SETUP MODE Activating the Setup Mode Contents of the Setup Mode	
□ GLOSSARY (	OF TEAMSG	3L-1
□ INDEX		IN-1

CHAPTER 1 COMPONENTS

COMPONENTS

CHAPTER 2 INSTALLATION AND CONNECTIONS

INSTALLATION AND CONNECTIONS

CHAPTER 3 OPERATING INSTRUCTION

OPERATING INSTRUCTION

CHAPTER 4 DOCUMENT SPECIFICATION

DOCUMENT SPECIFICATION

CHAPTER 5 SPECIFICATIONS

SPECIFICATIONS

CHAPTER 6 SETUP MODE

SETUP MODE

**GLOSSARY OF TERMS** 

GLOSSARY OF TERMS

**INDEX** 

INDEX



After unpacking the scanner, confirm that all the components have been received. This chapter describes the components of the scanner, part names, and operator panel arrangement and their function.


**Checking the Components** 

**Units and Assemblies** 

**Operator Panel** 

# Cheking the Components


These high precision components must be handled with care. Confirm that all the components shown in the following figure have been received. If any component is missing, please contact your sales agent.




### **Units and Assemblies**


This section shows the exterior view and assemblies of the scanner. This section also provides names of each part and describes their functions.

#### **■** Units






M3097DE



#### M3097DG


No.		Function			
1	Document cover:	Closed over and holds a document to be read.			
2	Document bed:	A document to be read is placed on the bed also called			
		Flatbed (FB).			
3	Document holding pad:	Presses a document to the document bed.			
4	Automatic document feeder (ADF):	Automatically feeds documents to the reading position.			
(5)	Stacker:	Stacks the read documents.			
6	Power switch:	Turns the power on or off.			
7	Operator panel:	The indication panel indicates the status of the scanner.			
8	ADF paper chute:	Holds the documents to be fed by the automatic			
		document feeder.			
9	ADF lever:	Opens or closes the automatic document feeder to			
		remove documents jammed in the feeder.			
10	Power inlet:	To be connected to an AC power outlet with the power			
		cable.			
11)	Interface connectors:	To be connected to the host system with interface cables.			
12	Third party slot:	Reserved. (M3097DE)			
13	Memory cover:	Reserved.			



# **Operator Panel**

The operator panel is located at the upper right hand side of the scanner. The panel consists of an LCD (24 character x 2 line), LEDs and buttons.

#### ■ Arrangement



Operator panel



### **■** Button/LED Function

Name of the button and LED		Function				
Button Next		LCD displays the next screen.				
	Previous	LCD displays the Previous screen.				
	<b>←</b>	Moves the cursor to the left				
	$\rightarrow$	Moves the cursor to the right				
off "CHECK" and retu		<ul> <li>When "CHECK" LED lights, pressing this button releases error status (turn off "CHECK" and returns to "Scanner Readry" screen).</li> <li>When you are setting on the operator panel, pressing this button returns to "Scanner Ready" screen immediately.</li> </ul>				
ENTER		The parameter selected by cursor becomes effective.				
	(START)	When Manual start mode is set or "READ" lamp lights, this button is effective and starts the reading.				
	(STOP)	This button is effective during reading operation and stops the reading.				
LED	0	Indicates that the scanner is ON.				
	READ	Indicates that the scanner is reading or ready to read.				
	CHECK	<ul> <li>If it lights, it means that some alarm occurred. Pressing "Exit" button turns off "CHECK" lamp.</li> <li>If it blinks at one second cycle, it means that jam or double feed is detected. Removing the jammed paper turns off "CHECK" lamp. At double feed, pressing "Exit" button turns off "CHECK" lamp.</li> <li>If it blinks at four seconds cycle, it means that ADF cleaning is necessary.</li> </ul>				

### **■** Counter Display

The scanner is provided with the counter display.



Counter	Function
Paper counter	Paper counter counts the scanned sheet from the start of reading to Paper Empty or an error detection. So this counter is automatically reset at the start of reading.
Abrasion counter	Abrasion counter counts the accumulated number of the scanned sheet. This counter increments at every 10 sheets. This counter is useful to check the cleaning cycle or parts replacement cycle. How to reset is described in Chapter 6.

#### Operation status

Operation status is indicated by the following message:

<Power-on>

Warming - up Now!!

<Reading>

Now Reading!

<Waiting for Start> (Only M3097DE)

Scanner displays followig screen when waiting Start button pressed.

Please Start SW ON

<Cleanig request>

When the Pick roller cleaning is necessary, the scanner displays as follows on the upper line.

Please Clean Pick-roller Now Reading

When the ADF glass cleaning is necessary, the scanner displays as follows on the LCD.

Please Clean ADF glass Now Reading

Clean the Pick roller or ADF glass in accordance with the manual, "Cleaning and Maintenance".

#### Temporary error

<Hopper empty>

Paper Empty

This message is displayed if there is no more paper on the ADF paper chute during a read operation in ADF mode. Fill the ADF paper chute with paper. To enable the read operation, press the stop button.

<Jam>

Paper Jam

This message is displayed if a ducument is jammed in the ADF. See "Cleaning and Maintenance" for removing jammed ducuments.

<ADF cover open>

ADF-Cover Open

This message is displayed if the ADF is not closed completely. Close the ADF completely, and enable the read operation.

<Double feed error>

Double Feed Error

This message is displayed when the ADF detects the Double feed error. Check the document and re-scan the ducument.

#### Alarm

One of the following message is displayed if an error occurs in the scanner. If one of the following error message is displayed, turn the power off and then on again. If the same message is displayed, contact your service representative.

·	
<optical alarm="" front=""></optical>	Optical Alarm (F)
<optical alarm="" back=""></optical>	
	Optical Alarm (B)
<fb alarm="" mechanism=""></fb>	Mechanical Alarm
<motor alarm="" fuse=""></motor>	
	Motorfuse Alarm
<lamp alarm="" fuse=""></lamp>	Lampfuse Alarm
<lmage alarm="" transfer=""> (M3097DG)</lmage>	Image Transfer Alarm
<memory alarm=""></memory>	
swemery diamin	Memory Alarm
<eeprom alarm=""></eeprom>	
	EEPROM Alarm



# **INSTALLATION AND CONNECTIONS**

The chapter describes how to install and connect the scanner.

**Precautions** 

Inspection

**Removing the Carrier Fixing Bracket** 

**Cable Connection** 

**Mounting the Stacker** 

SCSI-ID Setting (M3097DG)

#### **Precautions**

This section describes precautions when installing the scanner.


Do not install the scanner in the following places and environments.

- Place the scanner away from electrical noise sources, strong magnetic fields and air flow. If the scanner
  is used near an air conditioner, copying machine, or TV set, the scanner may operate incorrectly.
- Keep the scanner out of the sun and away from heaters. These environments may shorten the scanner life or cause hardware failures.
- Do not install the scanner in a place where vibrations may occur. This environment may cause hardware failures or may cause the scanner to operate incorrectly.
- Do not install the scanner in a humid, dusty, or damp places. These environments may shorten the scanner life or cause hardware failures. Do not place the scanner where liquid spills may occur.
- Be aware of the static electricity. Be sure that the flooring and the desk are made of materials that do not generate the static electricity.


See Chapter 5 SPECIFICATIONS for the informantion such as the size of the installation space.

### Inspection

This section describes how to check the labels.



#### Label A (An example)



#### Label B (An example)

MODEL	IMAGE SCANNER M3097DE	Rev. Label	MO	DEI	L NA	AME						
PART NO.	CAO **** - ****		0	1	2	3	4	5	6	7	8	9
SER. NO.	****	[][]	0	1	2	3	4	5	6	7	8	9
DATE	1997-** 2*.*Kgf	[1][1]	0	1	2	3	4	5	6	7	8	9
FUJ	ITSU LIMITED										2	ÎNS

### Removing the Carrier Fixing Bracket

To keep the scanner from being damaged during shipping, the carrier unit is fixed with a bracket. After placing the carrier unit at the installation place, remove this bracket as explained below.

Place the image scanner on the edge of the desk top so that the left side (where ADF is placed) of the scanner extends from the desk top. Do not set the image scanner upside down or on its side.

CAUTION
Do not extend the scanner more than 20cm (8 in.) from the desk.


Good

Bad

Bad

Bad

less than 20cm
(8 in.)




### **Cable Connection**

This section describes how to connect the cables. Connect the cables as follows:


### **■** Turning the power switch off

Press "O" side of the power switch to turn the power off.



#### **■** Connecting the power cable


Connect the power cable to the power inlet of the device and a power outlet.



#### **■** Connecting the interface cable


#### (M3097DE)

Connect the video interface and RS-232C interface cables and secure them with hooks and screws. Connect the other ends to the host machine.




#### (M3097DG)

Connect the SCSI interface cables and secure them with hooks and connect the other ends to the host machine. When the scanner is at the terminal side, connect the terminator to the connector to which an interface cable is not connected.



# Mounting the Stacker

Mount the stacker using the following procedure.



### SCSI-ID setting (M3097DG)

The default of SCSI-ID is 5. SCSI-ID is set by Setup mode of the operator panel. The procedure to set SCSI ID is;

1 Turn the power ON by pressing "I" side of the power switch. The scanner displays "Scanner Ready" on the lower line of LCD.

```
Scanner Ready >
```

2 Then press "Next" button. The scanner displays "Mode select 1".

```
Mode select 1
M Manual mode Change?
```

**3** Then press "Next" button. The scanner displays "Mode select 2" meaning that setup mode is ready. Then press "ENTER" button.

```
Mode select 2
! Set up mode Change?
```

4 Then press "ENTER" button. The scanner displays as follows.

```
! 0 1 Double Feed Chck
= No/Yes--> 10/15/20mm
```

**5** Press "Previous" once, then the scanner displays "SCSI ID" on the upper line of the LCD.

```
! 1 0 S C S I D
= 0 / 1 / 2 / 3 / 4 / 5 / 6 / 7
```

- **6** Select SCSI ID by pressing " $\rightarrow$ " or " $\leftarrow$ " button, and press "ENTER". (SCSI ID is set.)
- 7 Press "Exit" to return to "Scanner Ready" screen.



# **OPERATING INSTRUCTION**

This chapter describes how to turn the power on, and also describes button specification and reading mode setting.

Refer to Cleaning and Maintenance about information on loading document and maintenance.

**Turning the Power On** 


Reading Mode Setting (M3097DE)

**Manual Feed Mode Setting** 

# Turning the Power On

This section describes how to turn the power on.

Press "I" side of the power switch. The power goes on and the green Power lamp at the operator panel lights.



### Reading Mode Setting (M3097DE)

This section describes the button specifications and setup details for each of the simplex (front-side), duplex (front-side) and duplex (back-side) reading modes.

When reading mode is set by the command from the host computer, the following button operation is not required.

At any time you press [Exit], scanner returns to screen M1

1 Turn the power ON and verifty that "Scanner Ready" is displayed on LCD. <Screen M1>

Scanner Ready

2 Press Next then the scanner displays Screen M2

<Screen M2>

- 3 Press ENTER then the scanner displays Screen 1.
- 4 Select ADF or FB by pressing ← or → then press ENTER. The scanner displays Screen 2.

<Screen 1>

△01 Reading device =ADF/FB

5 Select "Simplex" or "Duplex" by pressing
← or →. Then press Enter. The scanner displays Screen 3.

<Screen 2>

△02 Reading face
=Simplex/Duplex

6 Select "Portrait" or "Landscape" by pressing ← or →. Then press ENTER. The scanner displays Screen 4.

<Screen 3>

d03 Paper Direction
=Portrait/Landscape

- 7 Select Size by pressing ← or →. Then press NTER. The scanner displays Screen 5.
- 8 Select Resolution by pressing ← or →.
  As the cursor moves to left 100/150 may appear. Then press ENTER. The scanner displays Screen 6.
- <Screen 5>

  105 Resolution
  = 200/240/300/400/600
- <Screen 6>

  ②06 Front Density

  = ■■■/■■/■■□/■■□/■□□□

#### Density display

Without IPC option	With IPC-2D or IPC-3D option	Descreption
		Very dark
		Dark
	AT1 *	Dynamic Threshold (DTC mode)
	AT2 *	Simplified Dynamic Threshold (IPC mode)
		Normal
		Light
		Very light

<Screen 4>

<sup>\*</sup> This parameter appears only when IPC-2D or IPC-3D is installed.

- **11** Select Front Halftone by pressing ← or →.

<Screen 7>

<Screen 8>

d08 Front Halftone
=No/HT1/HT2/LP1/LP2

Parameter	Description	
No	Halftone is OFF. Therefore binary reading is specified.	
HT1	Halftone with dither is specified.	
HT2	Halftone with error diffusion is specified.	
LP1 *	Automatic separation with dither is specified.	
LP2 *	Automatic separation with error diffusion is specified.	

<sup>\*</sup> This parameter appears only when the IPC-2D or IPC-3D is installed.

Press ENTER to admit. Scanner displays Screen 9.

- 12 Select Back Halftone (when "Duplex" was specified) by pressing ← or →. The parameters are same as 11. Press ENTER to admit. Then scanner displays Screen 10.
- **13** Select Front Document Type by pressing ← or →.

<Screen 9>

d09 Back Halftone = No/HT1/HT2/LP1/LP2

<Screen 10>

10 Front Document Type = L.(Line)/P.(Photo)

Parameter	Description
L.(Line)	White level following is ON. Top 3mm part of the document must be left blank (grounding color is dropout color). It is useful to read line art or text.
P.(Photo)	White level following is OFF. It is useful to read photograph.

Press ENTER to admit. The scanner displays Screen 11.

- 14 Select Back Document Type (when "Duplex" was specified) by pressing ← or →. The parameters are same as (13). Press ►NTER to admit. Then scanner displays Screen 12.
- 15 Confirm what you have specified.

  If some parameter needs to change, press Next or Previous to select screen and re-select the parameter by pressing


  or → and finally press ENTER.

  If all parameter is acceptable, press Exit to return to "Scanner Ready" screen.

<Screen 12>



<Screen 12 (Example)>



# Manual Feed Mode Setting

In this mode, the scanner waits for some predetermined time without issuing "Paper Empty" after all documents are read. This predetermined time (time-out limit) is specified by Setup mode. Therefore you can set next documents on ADF chute without interrupting reading operation. The procedures for setting manual feed mode are as follows.

1 Turn the power ON and verify that "Scanner Ready" is displayed on LCD. <Screen M1>
Scanner Ready

2 Press Next then the scanner displays Screen M2.

<Screen M2>

Mode Select 0 △Reading mode Change?

3 Press Next then the scanner displays Screen M3.

<Screen M3>

Mode Select 1

M Manual mode Change?

4 Press ENTER then the scanner displays Screen M4.

<Screen M4>

M01 Manual feed = No / Yes

- 5 Select "Yes" by pressing →. Then press ENTER.
- 6 Press Exit to return to "Scanner Ready" screen. Note that "Manual Feed" is shown on LCD. This means that the scanner is in Manual Feed mode.

<Screen M1>

Manual feed Scanner Ready



# **ADF DOCUMENT SPECIFICATION**


This chapter describes the document size and document guality of the ADF.

**Document Size** 

**Document Quality** 

# **Document Size**

The following figure shows document sizes that the scanner can read.



Scanner	Max	imum	Minimum		
Scanner	A B		Α	В	
M2007DE/DC	207 (11 7 in)	422 (17 in)	148 (5.8 in)	105 (4.1 in)	
M3097DE/DG	297 (11.7 in)	432 (17 111)	105 (4.1 in)	148 (5.8 in)	

(Unit: mm)

# **Document Quality**

This section describes document types and weights available for the scanner, and precautions.

## ■ Document type

The recommended paper type for document is as follows:

- Woodfree paper
- Plain paper (for example, the paper specified for XEROX 4024)

When using all other type paper, check that it is successfully fed by ADF before performing a reading operation.

# **■** Paper weight

The paper weight is as follows:

• 52 to 104 g/m<sup>2</sup> (3.9 to 27.8 lb)

#### ■ Precautions

The following documents may be hard to read by ADF. Preliminary document feed test may be necessary to avoid the unexpected errors. If the document slips in ADF (JAM error) or double feed occurs frequently, read them by flatbed.

- Paper with clips or staple
- · Paper with wet ink
- Paper of which thickness is not constantly equal. (like envelope)
- Paper with large rumples or curl. (See NOTE on the next page.)
- Paper with folds or tears
- Tracing paper
- Coating paper
- Carbon paper
- Paper smaller than 148 mm x 105 mm size, or larger than A3 or Double Letter
- Other than paper; clothes, metal foil, or OHP film
- Photographic paper
- Paper with notches on its side
- Other than rectangle paper
- Paper that is very thin

# **CAUTION**

Do not feed an important original document to prevent damage to it on the off chance.

When scanning a translucent document, set the density to light mode.

Carbon-less papers have the chemical composition which damages the pad and pick roller. Therefore, note the following remarks

Cleaning: If the miss pick occurs frequently, clean the pad and pick roller in accordance with


the "Cleaning and Maintenance".

Replacement of parts: The life of the pad and the pick roller may be shorter than the case that PPC

document is fed.



Paper should be straightened to fit the condition below.





This chapter describes the installation specifications, dimensions, consumables, option.

**Installation Specifications** 

**Dimensions** 

**Consumables** 


**Option** 


# **Installation Specifications**

The following table lists the installation specifications of the scanner.

	Item	Specification				
Dimensions (mm)		Width	Depth		Height	
Dimensions	(mm)	696 (27.4 in)	497 (1	9.6 in)	234 (9.2 in)	
Weight (kg)		20 (44.2 lb.)				
	Voltage	100 to 120 VAC, 220	100 to 120 VAC, 220 to 240 VAC ±10 %			
Input power	Phases	Single-phase				
	Frequency	50/60 + 2% -4% Hz				
Power consu	ımption	120 VA or less				
	Device status	Operating		Not operating		
Ambient condition	Temperature	5 to 35°C (41 to 95°F)			-20 to 60°C (-4 to 140°F)	
	Humidity	20 to 80 %		8 to 95 %		
Heat capacity	у	78 kcal/H (312 BTU/H)				

# **Dimensions**





(unit: mm)

# Consumables

The following table lists consumables used for the scanner. Be sure to keep some consumables in stock. Customer is responsible to change these items periodically. The abrasion counter can be used to check the number of scanned documents.

Name	Specification	Remark
Pad ASY	PA03951-0021	Up to 100,000 sheets or one year.
Pick roller	PA03951-0025	Up to 200,000 sheets or one year. (Two roller are included.)

# Option

The following table lists options of the scanner.

Name	Specification	Remark
Extended Memory	TBD	16MB, EDO SIMM, 72pin, 60ns without parity One per unit
IPC-2D*	CA01952-0192	Image Processing Circuit One per unit
IPC-3D*	CA02919-0511	Image Processing Circuit One per unit

<sup>\*</sup> One of these option can be installed at a time Contact your Fujitsu sales agent for more information.



This chapter describes the setup mode of the scanner.

**Activating the Setup Mode** 

**Contents of the Setup Mode** 

# Activating the Setup Mode

This section describes how to activate the setup mode.

- 1 Turn the power ON. Then the scanner displays "Scanner Ready" on LCD.
- Scanner Ready
- 2 If the scanner is M3097DG, go to the procedure 3. Press Next then the scanner (M3097DE) displays Screen M2.
- <Screen M2>

<Screen M1>

Mode Select 0 △Reading mode Change?

- 3 Press Next then the scanner displays Screen M3
- <Screen M3>

Mode Select 1 M Manual mode Change?

- 4 Press Next then the scanner displays Screen M4
- <Screen M4>

Mode Select 2
Setup mode Change?

- 5 Press ENTER. Now the scanner is at Screen 41 (page 6-3) in Setup mode.
- NOTE

Any time you press Exit, you can return to "Scanner Ready" screen.

# Contents of the Setup Mode

This section describes the contents of the setup mode.

No	Item	Description	Selectable parameters	Default
1	Double feed check	Double feed is detected by checking the document length one by one.**	Tolerance: No/10/15/20mm	No
2	IPC pre-setting	Scanner automatically sets the recommended reading parameters. 5 sets of recommended parameters are available.	Document: No/1/2/3/4/5	No
3	Rest of abrasion counter	Abrasion counter can be reset.	-	-
4	Pick start time setting	The time from the document Insertion to the start of picking is specified. User can select most comfortable Pick start time for the job.	Time: 0.2 to 29.8 sec	1.0 sec
5	Time-out limit setting	The time that the scanner waits for next ducument insertion after last document scanned can be specified.	Time: 27 values from 1 to 1999 sec	30 sec
6	ADF front offset setting*	Horizontal and vertical offset of the front side image by ADF is specified.	Offset: H:-2 to +3mm V:-2 to +3mm	Offset: H: 0 mm V: 0 mm
7	ADF back offset setting*	Horizontal and vertical offset of the back side image by ADF is specified.	Offset: H:-2 to +3mm V:-2 to +3mm	Offset: H: 0 mm V: 0 mm
8	FB offset setting*	Horizontal and vertical offset of the FB image is specified.	Offset: H:-2 to +3mm V:-2 to +3mm	Offset: H: 0 mm V: 0 mm
9	IPC/Memory status display	The type of IPC option (IPC-2D or IPC-3D) and total memory installed are displayed.		
10	SCSI ID setting	SCSI ID is selectable.	SCSI ID: 0/1/2/3/4/5/6/7	5

<sup>\*</sup> This offset means the deference from the value adjusted by automatic offset adjustment.

<sup>\*\*</sup> The document length on ADF paper chute must be same. If the completely overlapped sheets are fed, the scanner cannot detects the double feed.

# ■ Setting double feed detection

When you set the using of double feed detection, you must set as follows:

1 Press Next or Previous and let the scanner display Screen 41.

<Screen 41>

! 01 Double Feed Check  $= No/Yes \rightarrow 10/15/20mm$ 

2 At Screen 41, press → or ← to select the tolerance (10 or 15 or 20mm) and press ENTER to activate the double feed detecton. Scanner compares the length of the scanned document with the length of the first document. When the length of the scanned document is longer or shorter than the length of the first document exceeding the tolerance, double feed is detected. If you want to disable the double feed, select "No" then press ENTER. Press Exit to return to "Scanner Ready" screen.



Double Feed detection is effective only when the length of the all document on ADF is same.



Scanner stops document feeding at the double feed detection. When the document in ADF is not the double fed document, previous document may be double fed.



If the completely overlapped sheets are fed, the scanner can not detect the double feed.

# ■ Setting IPC pre-set mode

When you set the using of IPC-2 pre-set mode, you must set as follows:

- 1 Press Next or Previous and let the scanner display Screen 42.
- 2 At Screen 42, press → or ← to select the document number and press ENTER to activate the IPC pre-setting. Then the scanner displays Screen 42-1. Go to procedure 3. If you want to disable the IPC pre-setting, select "No" then press ENTER. Finally press Exit to return to "Scanner Ready" screen.

3 At Screen 42-1, select "Yes" to activate the IPC pre-setting or select "No" to disable the IPC pre-setting. Note that when you activate the IPC pre-setting, the IPC setting by Host computer is ignored. Finally press ENTER, then the scanner displays next item, Screen 43.

<Screen 42-1>

! 02-1 IPC Host Setting
Ignore Yes/No

<Classification of document number>

Document number are classified in line-art scanning as follows:

The horizontal axis shows the background density/color of paper.

The vertical axis shows the density of charcter/line.

		Backgrou	Background density Background color			
		Normal← →Dark		Red	Green	Blue
Character density	Normal ↑	①: Normal background and character.	③: Dark background and normal-density character.			
	↓ Light	②: Normal background and light character.		4: Light character on red paper.	⑤: Light character on green paper.	

<sup>1) - 5</sup> are the document number set in setup mode.

# NOTE

- When IPC pre-set is executed in setup mode Scanner checks that IPC-2D or IPC-3D are installed when the scanner enters in IPC pre-set. If IPC-2D or IPC-3D is not installed, the scanner does not enter in IPC pre-set.
- When IPC pre-set mode is executed When IPC pre-set mode is executed in online mode, the reading parameter is valid or invalid (Host setting is invalid) as follows:

		Reading parameter						
	Reading	Reading Tranfer Transfer Resdution Start of Density Line-art Halftone						
	mode	mode	rate		reading		/ Photo	
Valid	0	0	0	0	0			
Invalid						0	0	0

	Reading parameter							
	DTC	Size	Portrait/	Picking	Document	r patterns	Contrast	Automatic
			Landscape		selection			separation
Valid		0	0	0	0			
Invalid	0					0	0	0

	Reading parameter						
	Conversion	Sharpness	Outline extraction	Overlay	Simplified DTC	Zooming	
Valid	0					0	
Invalid		0	0	0	0		

#### ■ Reset of abrasion counter

When you reset the abrasion counter, you must set as follows:

- 1 Press Next or Previous and let the scanner display Screen 43.
- 2 At Screen 43;
  If you want to reset the abrasion counter, select "Yes" by ← or → button and press ENTER. Go to procedure 3.
  If you do not want to reset the abrasion counter, select "No" and press ENTER.
  Finally press Exit to return to "Scanner Ready" screen.
- 3 At Screen 43-1;
  If you want to reset the abrasion counter, select "Yes" and press ENTER. If you do not want to reset, select "No" and press ENTER.

<Screen 43>

!03 Abrasion Counter = XXXXXX Reset No/Yes

<Screen 43-1>

!03-1 Are you sure?

# ■ Setting pick start time

When you set the pick start time, you must set as follows:

- 1 Press Next or Previous and let the scanner display Screen 44.
- 2 At Screen 44, press → to increase the Pick start time or press ← to decrease the Pick start time. Then press ENTER to activate the setting. Finally press Exit to return to "Scanner Ready" screen.

<Screen 44>

!04 Pick start time = 1.0 Sec

# ■ Setting time-out limit

- 1 Press Next or Previous and let the scanner display Screen 45.
- 2 At Screen 45, press to increase the number or press to decrease the time-out limit. Then press ENTER to activate the setting. Finally press Exit to return to "Scanner Ready" screen.

<Screen 45>

!05 Time-out limit = 30 Sec

# **■** Setting Offset

- 1 Press Next or Previous and let the scanner display as follows;
  - Front Offset by ADF: Screen 46.Back Offset by ADF: Screen 47.
  - Offset of Flatbed : Screen 48.

<Screen 46>

!06 ADF Front Offset Change? No/Yes

<Screen 47>

!07 ADF Back Offset Change? No/Yes

<Screen 48>

!08 FB Offset Change? No/Yes

2 Select "Yes" by pressing ← or → button, and press ENTER. Then scanner displays Screen A.

<Screen A>

! 0 X-1 Return to default?

3 At Screen A, if you want to let the offset return to default, select "Yes" otherwise "No" then press ENTER. The scanner displays Screen B.

<Screen B (Example of ADF Front Offset)>

$$! 06-2$$
 Front Offset H  
H= +0.0 mm (+: Left)

<Screen B (Example of ADF Back Offset)>

$$!07-2$$
 Back Offset H  
H=  $+0.0$  mm (+:Left)

<Screen B (Example of FB Offset)>

4 At Screen B, press → to increase the offset or press (-) to decrease offset. The increment or decrement is 0.5 mm. Then press ENTER to activate the setting. The scanner displays Screen C.

<Screen C (Example of ADF Front Offset)>

$$!06-3$$
 Front Offset V  
V= +0.0mm (+:Up)

<Screen C (Example of ADF Back Offset)>

$$!07-3$$
 Back Offset V  
V= +0.0 mm (+:Up)

<Screen C (Example of FB Offset)>

$$!08-3$$
 FB Offset V  
V= +0.0 mm (+:Up)

5 At Screen C, press → to increase the offset or press (-) to decrease offset. Then press ENTER to activate the setting. The scanner displays the next item of the setup mode.

# ■ Reviewing the IPC/Memory Status

- 1 Press Next or Previous and let the scanner display Screen 49.
- 2 Screen 49 displays the IPC option installed and total image memory installed. Press Exit to return to "Scanner Ready" screen.

<Screen 49 (Example of 32MB)>

!09 IPC/Memory Status IPC-2D/32MB(TOTAL)

(An example)

# ■ Setting SCSI-ID (M3097DG)

- 1 Press Next or Previous ant let the scanner display Screen 4A.
- 2 At Screen 4A, press ← or → to select SCSI-ID. Then press ENTER to activate the setting. Finally press Exit to return to "Scanner Ready" screen.

<Screen 50>

!10 SCSI-ID = 0/1/2/3/4/5/6/7

# **GLOSSARY OF TERMS**

#### A4 size

A standard paper size used in Japan and other countries. Paper size is 210 x 297 mm (8.25 x 11.6 inches).

#### **Abrasion counter**

Indicates when belts/rollers should be replaced. The number of read document accumulates until an operator resets the counter. It should be reset when consumables are replaced.

#### **ASCII**

The acronym for American Standard Code for Information Interchange.

ASCII is a set of 256 codes (numbered 0 to 255) used to communicate information between a computer and another device such as scanner.

# **Automatic separation**

The image processing method to detect the difference between text and photos and choose the threshold accordingly. Automatic separation allows the scanner to switch between line mode and half tone mode in one pass.

# Automatic start mode (<-> manual start mode)

In this mode the reading operation is activated only by START command.

# Back-side reading = Back-side scanning

Refers to reading the back-side of the document, specifically in Duplex reading mode.

#### **Bit**

The smallest unit of information in computer memory. A bit is a single digit, either a 1 or a 0, in the binary numbering system.

Eight bits equal one byte.

## Density

Refers to a measurement of the depth of the display in this manual.

#### **Dither**

Technique for producing halftone images representing the entire grayscale using two pixel levels black and white.

#### **Double feed detection**

A function which detects the status when multiple sheets are fed in the ADF unit.

# dpi

Dots per inch.

## **Drop-out color**

A color which is used to the document but does not appear in the read image.

# **Duplex reading mode**

Both sides of the document are read in this mode.

# **Equipment Error**

An error that is not recoverable by operator. Call CE.

#### **Error diffusion**

High-quality halftone (pseudo-grayscale) image production based on black-and-white pixel binarization. A pixel+s optical density and that of adjacent pixels are summed, with black pixels relocated in their order of density as they relate to adjacent pixels.

The purpose of this technique is to minimize the average error between read and printed densities. Density data for adjacent pixels is modified by diffusing errors on the objective pixel into several pixels, which are then binarized. This maintains high grayscale levels and resolution during reading, while suppressing more patterns by dotted halftone images such as newspaper photo graphs.

# **Filtering**

The quality of images written in pencil or ball-pointed pen and read depends on the reflective light characteristics of the ink or lead.

Dropped pixel+s may produce out lines, gaps or thin, barely connected lines due to even optical density. Filtering detects areas lighter than their surroundings and increases their density to improve image clarity.

# Front-side reading = Front-side scanning

Refers to reading the front-side of the document, specifically in Duplex reading mode.

# Halftone processing

Used to reproduce a photograph which includes a shade as an image composed of dots, namely a binary image. Dithering and error diffusion processing are examples of the halftone processing.

#### **Hexadecimal**

A base-16 numbering system(also commonly referred to as hex numbers). Since a base-16 system requires 16 digits, numbers 0 through 9 and letters A through F are used. It is convenient to express binary numbers in hexadecimal because fewer digits are required.

## Image emphasis

Density is decreased for lighter but not completely white areas adjacent to black areas. Weakening this emphasis eliminates spot noise or produces softened images.

## Image processing

An image is read with specified parameters.

#### Interface

The connection that allows communication from one part of a system to another. For example, electrical signals are transferred between the computer and scanner over an interface cable.

# Inversion (Reverse-image reading)

In reverse-image reading, data is changed from black to white and vice versa.

# IPC pre-set mode

While reading binary images, it is necessary to set the scanner according to the quality of the sheet to be read. In this mode these settings can be performed in advance by corresponding each setting to a pattern number.

#### IPC-2D or IPC-3D

Image processing option of this scanner.

## **IRAS**

Initialization of the hardware.

#### Landscape

A document is transported and read with the long side vertical to the moving direction.

#### Letter size

A standard paper size used in the U.S.A. and other countries. Paper size is  $8-1/2 \times 11$  inches (215.9 x 279.4 mm).

## Linedrawing mode

Selecting linedrawing mode makes threshold and contrast settings effective but prevents brightness from being set. The specified threshold value determines whether black or white pixels are scanned. Linedrawing mode is therefore appropriate for scanning text and line art images.

#### Manual Feed mode = Manual Mode

Requires the operator to feed each document manually to the ADF paper chute.

# Manual start mode (<-> automatic start mode)

The reading operation is activated by pressing the START button in this mode.

## Mirror image

The read image is symmetrically flipped to produce a mirror image of the original detected in the main scanning direction.

#### Noise removal

Isolated noise from an image appearing as black spots in white areas and voids in black areas is removed to improve image quality.

## Operator panel

A panel containing the scanner indicators and buttons. The operator panel is used to control scanner operations such as loading document, selecting features, and changing setup options.

## **Outline extraction**

The boundary between black and white areas is traced and the outline extracted for closed areas.

#### PAPER JAM

A warning informing the user that document is jammed in the transport unit, or that transportation is disabled because the transport unit is slippery. This warning also appears when a double fed is detected.

# Photograph mode (White level follower OFF)

Selecting photograph mode makes brightness and contrast settings effective but prevents the threshold from being set. With photograph mode, the darkness of image corresponds to the black-pixel density, making it suitable in scanning images such as photographs having gradations.

# Photo mode = photograph mode

A photograph is read properly in this mode.

#### Pick start time

The period from the manual insertion of the document until picking starts after the document passes the hopper empty sensor.

#### **Portrait**

A document is transported and read with the long side parallel to the moving direction.

## Paper counter

Indicates the total number of read document from reading start until the hopper becomes empty.

# **Read operation**

Refers to the reading operation including Simplex reading and Duplex reading.

#### **RS-232C** interface

A type of serial interface. See Serial interface.

#### **SCSI-ID**

Used to specify a particular SCSI device when the initiator selects a target or the target re-connects to the initiator.

#### Serial interface

A standard computer interface. Information is transferred between devices over a single wire (although other wires are used for control).

With a serial interface, an interface cable greater than 3 meters (10 feet) can be used. This is often necessary in networking environments, where the scanner may be shared.

#### **SETUP** mode

In this mode, users can view or set a variety of function in Off-line.

# Simplex reading mode

Only the front side of the document is read in this mode. Place the documents face-up at the center of the hopper table.

# **Smoothing**

Smoothing eliminates jaggies from slanted lines and curves. Irregular convexities are deleted and irregular concavities filled in. This is useful in OCR applications, for example.

# **Temporary Error**

An error that is recoverable by operator.

## **Terminator**

Devices with SCSI interface are daisy-chained. A resistor that includes terminal circuits needs to be placed at both ends of a cable when devices are daisy-chained.

## **Time-out limit**

This is the time which the scanner waits for next document insertion after the last document feeding. The scanner returns Paper Empty when no document is set after time-out limit.

# **INDEX**

Size 4-1 type 3-5, 4-2

A	A3 3-3 A4 3-3 Abrasion counter 1-7 Activating the Setup Mode 7-1 ADF 1-2, 1-3 ADF Lever 1-2, 1-3 mode 1-6 paper chute 1-2	Double feed check 6-2 feed detection 6-3 feed error 1-9 Duplex reading mode 3-2 (back-side) reading mode 3-2 (front-side) reading mode 3-2
	Alarm 1-10 Ambient condition 5-1 Arrangement 1-5 Assemblies 1-4	ENTER button 1-6 Exit button 1-6
_	F	Feeding direction 4-1
В	Belt 5-3 Button /LED Function 1-6	Halftone processing 3-4 Heat capacity 5-1 Hopper empty 1-9
С	Cable Connection 2-5 Carrier fixing bracket 2-4 Checking the Components 1-1 Connecting the interface cable 2-6 the power cable 2-5 Consumables 5-3 Contents of the Setup Mode 6-2 Conventions iii	Image processing circuit 5-4 IMPORTANT NOTE TO USERS is input power 5-1 Inspection 2-2 Installation Specifications 5-1 Interface connectors 1-2, 1-3 IPC pre-setting 6-2, 6-4 status 6-2, 6-9
D	Density 3-3, 3-4 Dimentions 5-1, 5-2 DLT (Double letter) 3-3 Document bed 1-2, 1-3 holding pad 1-2, 1-3 Quality 4-2	

L	Label	Power
	A 2-2	cable 1-1, 2-5
	B 3-3	consumption 5-1
	Landscape 3-2	inlet 1-2, 1-3
	LCD 1-5	switch 2-5, 3-1
	LCD Display 1-6	Precautions 2-1, 4-2
	LED 1-6	Previous button 1-6
	LG (Legal) 3-3	Trovious succin Tro
	LT (Letter) 3-3	_
	Li (Letter) 5-5	R Reading
		mode 3-2
M	Manual	face 3-2
IVI	feed mode 3-6	Reset of abrasion counter 6-6
	start mode 1-6	Resolution 3-3
	Memory	Reviewing the IPC/Memory Status 6-9
	cover 1-2, 1-3	reviewing the it of Memory Status 6 5
	status 6-2, 6-9	
	Status 0-2, 0-9	S Scanner 1-1
		Setting
N	Next button 1-6	double feed detection 6-3
1.		IPC pre-set mode 6-4
		Offset 6-7
0	Offset setting 6-2, 6-7	picking start time 6-6
	Operation Status 1-8	SCSI-ID 6-9
	Operator's Guide 1-1	time-out limit 6-7
	Operator panel 1-2, 1-5	
	Option 5-4	Setup mode 6-1, 6-2
	·	Simplex 3-2
		Size 3-3
P	Pad ASY 5-3	Specifications 5-1
	Paper	Stacker 1-2, 2-7
	counter 1-7	Start button 1-5, 1-6
	direction 3-2	Stop button 1-5, 1-6
	weight 4-2	
	Perface ii	T Terminator 1-1
	Pick	
	roller 1-4, 5-3	Temporary error 1-9
	start time 6-2, 6-6	Third party slot 1-2, 1-3
		Turning
	Plain paper 4-2 Portrait 3-2	Turning

the Power On 3-1 the power switch off 2-5

W Units 1-2 Units and Assemblies 1-2

Weight 5-1

button 1-6
button 1-6
(START) button 1-6
(STOP) button 1-6

# FUJITSU